


ercol

3444 SANDFORD
UPHOLSTERY



Thank you for purchasing this Sandford Upholstery. Please ensure instructions are read in full before attempting to assemble this product.

PREPARATION

This is a two person operation



Tools you will need



Included

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.






This product is **HEAVY**, it should be assembled as near as possible to the point of use.

TAKE CARE WHEN LIFTING to avoid personal injury and (or) damage to the product.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.


Read this leaflet in full before commencing assembly.

Fittings and parts checklist


A	Leg Assembly x 2	
B	Centre Leg x 1 - <i>Medium and Large Motion Loungers and Large Sofas only</i>	
C	Allen Key x 1	
D	Power Cable - <i>Motion Loungers Only</i>	
E	Power Adaptor - <i>Motion Loungers Only</i>	
F	Splitter Cable - <i>Motion Loungers Only</i>	

Sandford assembly instructions


1. Remove all cushions and carefully turn over the upholstery. Unpack the leg assemblies (A) and place on a blanket or carpeted floor to prevent scratching. If assembling a medium or large motion lounger or large sofa unpack the centre leg (B) as well.




2. Unscrew the transit feet by turning anti-clockwise. Once removed these can be disposed of.




3. Using the allen key (C) undo and keep the 10 bolts (a) on the underside of the upholstery.




4. Take one leg assembly (A) and line up the bolts holes on the upholstery. Take 5 of the bolts (a) previously removed and insert into each hole.





5. Tighten each bolt in a clockwise direction using the allen key provided (C).



6. Repeat steps 4 and 5 for the remaining leg assembly (A).




7. *Medium and Large Motion Lounger and Large Sofas only:* Take the centre leg (B) and line up with the bolt hole in the centre of the sofa. Hand tighten the centre leg by turning in a clockwise direction.




8. Carefully turn the upholstery back over and replace the cushions.

Connecting the power - Motion Loungers Only


1. All Sofa Sizes: It is best to position the sofa near the power source. Facing the back of the sofa find the two pin connectors towards the outer edges, 1 on each side. Push the 2 pin connectors into each side of the splitter cable (G).
2. Push the 2 pin connector on the splitter cable into the power adaptor (F) and close the locking cover.
3. Finally insert the power cable (E) into the power adaptor.




Positions your Sandford Motion Lounger can be used in



Position A - Closed



Position B - Partially Extended





Position C - Fully Extended

How to operate



1. Starting in a closed position, sit comfortably in the recliner, ensuring you are sitting as far back as possible.

2. Press the front button to lift the footrest.



3. The footrest will rise. Release button when comfortable or continue pressing until fully extended.

4. Press the back button to return the footrest to a closed position. Ensure the footrest is fully closed before standing.



Customer Care

Wood Furniture

Wood displays different grain patterns depending on which way it is cut. These are characteristics of the natural beauty of the wood. All timber surfaces will change colour and mellow over time.

Fabric Care

Every effort is made to keep colours consistent between batches, but fabric manufacturers cannot guarantee exact matching. All fabrics will fade in sunlight, to prolong the life of the fabric do not place it close to a heat source or in direct sunlight. Plump up cushions after use, especially fibre or feather cushions. If the cushions are reversible turn them at least once a week to minimise wear and maintain their appearance. To prevent dust and dirt accelerating wear, gently vacuum upholstery once a week or use a soft brush. For complete cleaning we recommend a specialist cleaning in situ. Accidental spills and stains should be treated as soon as possible, except mud which should be left to dry and then brushed off. Remove any solids, then blot up as much liquid as possible with white paper towel or a clean cloth. We recommend professional dry cleaning but some action can limit damage.

Important Information - Read carefully and retain for future reference:

- a) Test to BS 8474 2013;
- b) Ercol Furniture Ltd, Summerleys Rd, | Princes Risborough, Buckinghamshire, | HP27 9PX | UK
- c) Warnings:
 - 1) WARNING. This is an electrical item and should be treated with caution.
 - 2) WARNING. The motion lockout control must be engaged when the chair is not in use.
 - 3) WARNING. Always ensure that there is nothing to obstruct the free movement of the chair, for example children or pets, solid objects, e.g. a wall.
 - 4) WARNING. This chair is not suitable for use by children. Any children in the vicinity must be supervised at all times.
 - 5) WARNING. Take care when adjusting positions to avoid trapping or pinching body parts.
 - 6) WARNING. Do not sit on the footrest.
 - 7) WARNING. Only the occupant or a responsible person should operate the chair.
 - 8) WARNING. Exercise care when lowering into the chair as shock loads can severely damage the chair and the mechanism.
- d) Maximum load for safe operation of the chair is 110kg.
- e) If this is a large sofa, the centre leg must be attached as per the instructions before use.
- f) When the chair is not in use, please return to the upright seated position.
- g) Ensure the chair is fully in the upright seated position before standing.
- h) Never drag furniture when moving it, always lift it. Take care when handling or moving the furniture as careless handling may cause damage or injury. No liability will be accepted for damage or injury caused by incorrectly installed furniture.
- i) Please ensure the instructions provided have been read and clearly understood before use.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

Ercol Furniture Ltd, Summerleys Road, Princes Risborough, Buckinghamshire. HP27 9PX ercol.com